


## WIRING



## DIP SWITCHES

	ON	OFF
Sw3-1	Voltage Limiting	No Voltage Limiting
Sw3-2	No Var Speed	Var Speed
Sw3-3	4-Step Var Speed	12-Step Var Speed
Sw3-4	Unused	

## LINKS/JUMPERS

Links & jumper pins on the board are for factory use only.